



# EC70A-TGU

Fanless Robust Embedded System

User's Manual

## Copyright

This publication contains information that is protected by copyright. No part of it may be reproduced in any form or by any means or used to make any transformation/adaptation without the prior written permission from the copyright holders.

This publication is provided for informational purposes only. The manufacturer makes no representations or warranties with respect to the contents or use of this manual and specifically disclaims any express or implied warranties of merchantability or fitness for any particular purpose. The user will assume the entire risk of the use or the results of the use of this document. Further, the manufacturer reserves the right to revise this publication and make changes to its contents at any time, without obligation to notify any person or entity of such revisions or changes.

Changes after the publication's first release will be based on the product's revision. The website will always provide the most updated information.

© 2022. All Rights Reserved.

## Trademarks

Product names or trademarks appearing in this manual are for identification purpose only and are the properties of the respective owners.

## FCC and DOC Statement on Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

## Notice:

1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Shielded interface cables must be used in order to comply with the emission limits.

# Table of Contents

|   |           |
|---|-----------|
| Chapter 1 - Introduction.....   | 6         |
| Overview.....   | 6         |
| Front View.....   | 6         |
| Rear View.....  | 6         |
| Dimensions.....   | 7         |
| Key Features.....   | 7         |
| LED Indication.....   | 7         |
| Specifications.....   | 8         |
| Chapter 2 - Hardware Installations.....                                     | 10        |
| Removing the Chassis Cover.....   | 10        |
| Installing the SO-DIMM Module.....  | 11        |
| COM3 Jumper Setting.....  | 12        |
| Chapter 3 - BIOS Settings.....  | 13        |
| Overview.....   | 13        |
| Updating the BIOS.....  | 13        |
| Main.....   | 14        |
| Advanced.....   | 14        |
| CPU Configuration.....  | 15        |
| Power & Performance.....  | 15        |
| Power & Performance ▶ <b>CPU- Power Management Control</b> .....            | <b>16</b> |
| PCH-FW Configuration.....   | 16        |
| Trusted Computing.....  | 17        |
| NCT6126D Super IO Configuration.....  | 17        |
| NCT6126D HW Monitor.....  | 18        |
| NCT6126D HW Monitor ▶ <b>Smart FAN Function</b> .....                       | <b>18</b> |
| Serial Port Console Redirection.....  | 19        |
| Serial Port Console Redirection ▶ <b>Console Redirection Settings</b> ..... | <b>19</b> |
| ACPI Settings.....  | 20        |
| USB Configuration.....  | 21        |
| Network Stack Configuration.....  | 21        |
| CSM Configuration.....  | 22        |
| Tls Auth Configuration.....   | 22        |
| Chipset.....  | 23        |
| Graphics Configuration.....   | 23        |
| PCH-IO Configuration.....   | 24        |
| PCH-IO Configuration ▶ <b>PCI Express Configuration</b> .....               | <b>24</b> |
| PCH-IO Configuration ▶ <b>SATA And RST Configuration</b> .....              | <b>25</b> |
| PCH-IO Configuration ▶ <b>HD Audio Configuration</b> .....                  | <b>25</b> |
| Security.....   | 26        |
| Secure Boot.....  | 26        |
| Boot.....   | 27        |
| Save & Exit.....  | 27        |

## About this Manual

This manual can be retrieved from the website.

The manual is subject to change and update without notice, and may be based on editions that do not resemble your actual products. Please visit our website or contact our sales representatives for the latest editions.

## Warranty

1. Warranty does not cover damages or failures that arises from misuse of the product, inability to use the product, unauthorized replacement or alteration of components and product specifications.
2. The warranty is void if the product has been subjected to physical abuse, improper installation, modification, accidents or unauthorized repair of the product.
3. Unless otherwise instructed in this user's manual, the user may not, under any circumstances, attempt to perform service, adjustments or repairs on the product, whether in or out of warranty. It must be returned to the purchase point, factory or authorized service agency for all such work.
4. We will not be liable for any indirect, special, incidental or consequential damages to the product that has been modified or altered.

## About this Package

The package contains the following items. If any of these items are missing or damaged, please contact your dealer or sales representative for assistance.

- 1 EC70A-TGU system unit
- Remote switch cable (100cm)
- Mounting screws for M.2 module
- Rubber foot screws
- Grounding screw

Note: The items are subject to change in the developing stage. The product and accessories in the package may not come similar to the information listed above. This may differ in accordance with the sales region or models in which it was sold. For more information about the standard package in your region, please contact your dealer or sales representative.

## Static Electricity Precautions

It is quite easy to inadvertently damage your PC, system board, components or devices even before installing them in your system unit. Static electrical discharge can damage computer components without causing any signs of physical damage. You must take extra care in handling them to ensure against electrostatic build-up.

1. To prevent electrostatic build-up, leave the system board in its anti-static bag until you are ready to install it.
2. Wear an antistatic wrist strap.
3. Do all preparation work on a static-free surface.
4. Hold the device only by its edges. Be careful not to touch any of the components, contacts or connections.
5. Avoid touching the pins or contacts on all modules and connectors. Hold modules or connectors by their ends.



### Important:

Electrostatic discharge (ESD) can damage your processor, disk drive and other components. Perform the upgrade instruction procedures described at an ESD workstation only. If such a station is not available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the system chassis. If a wrist strap is unavailable, establish and maintain contact with the system chassis throughout any procedures requiring ESD protection.

## Safety Precautions

- Use the correct DC / AC input voltage range.
- Unplug the power cord before removing the system chassis cover for installation or servicing. After installation or servicing, cover the system chassis before plugging in the power cord.
- There is danger of explosion if battery incorrectly replaced.
- Replace only with the same or equivalent specifications of batteries recommend by the manufacturer.
- Dispose of used batteries according to local ordinance.
- Keep this system away from humid environments.
- Make sure the system is placed or mounted correctly and stably to prevent the chance of dropping or falling may cause damage.
- The openings on the system shall not be blocked and shall be kept in distance from

other objects to make sure of proper air ventilation to protect the system from over-heating.

- Dress the cables, especially the power cord, so they will not be stepped on, in contact with high temperature surfaces, or cause any tripping hazards.
- Do not place anything on top of the power cord. Use a power cord that has been approved for use with the system and is compliant with the voltage and current ranges required by the system's electrical specifications.
- If the system is to be unused or stored for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
- If one of the following occurs, consult a service personnel:
  - The power cord or plug is damaged.
  - Liquid has penetrated the system.
  - The system has been exposed to moisture.
  - The system is not working properly.
  - The system is physically damaged.
- The unit uses a three-wire ground cable which is equipped with a third pin to ground the unit and prevent electric shock. Do not defeat the purpose of this pin. If your outlet does not support this kind of plug, contact your electrician to replace the outlet.
- Disconnect the system from the electricity outlet before cleaning. Use a damp cloth for cleaning the surface. Do not use liquid or spray detergents for cleaning.
- Before connecting, make sure that the power supply voltage is correct. The device is connected to a power outlet which should be grounded connection.



The system may burn fingers while running.

Wait for 30 minutes to handle electronic parts after power off.

## Chapter 1 - Introduction

### ► Overview



Front View



\*Default

- 1 Power Button (w/status LED)
- 2 HDD LED
- 3 VGA
- 4 COM 4 (RS232)
- 5 COM 1 (RS232\*/RS422/RS485)
- 6 COM 2 (RS232\*/RS422/RS485)
- 7 Antenna Hole
- 8 Reset Button

Rear View




SKU 3



\*Default

- 9 COM 3 (RS232\*/8-bit DIO)
- 10 DC-in (9V ~36V)
- 11 LAN 1 ~ 2
- 12 LAN 3
- 13 USB 3.1
- 14 LAN 4
- 15 HDMI 1 ~ 2

► Dimensions



► Key Features

**Tiger Lake:**

Intel® 11th Gen Core™ Tiger Lake UP3 Processor, TDP=15W

**Triple Displays:**

2 HDMI (4K@30Hz) + 1 VGA (2K@60Hz)

**On Board Memory:**

On board memory and 1 SO-DIMM DDR4

**5G Support:**

Support M.2 B key 3042/3052 5G-NR module

**Rich I/O:**

Up to 4 LAN, or 6 USB

► LED Indication



**1 Status LED**

| Suspend Mode | LED Behavior              |
|--------------|---------------------------|
| S0           | Always ON                 |
| S1           | Quick Blink (cycle 1 sec) |
| S3           | Slow Blink (cycle>1 sec)  |
| S4, S5       | Off                       |

**2 HDD LED**

| LED Behavior | Status                         |
|--------------|--------------------------------|
| Blink        | Disk access activity           |
| Off          | HDD present or HDD not present |

► Specifications

|                  |                        |   |
|------------------|------------------------|---|
| <b>SYSTEM</b>    | <b>Processor</b>       | 11th Gen Intel® Core™ i7/i5/i3 Processors<br>Intel Embedded Series<br>Intel® Core™ i7-1185G7E Processor, 4C8T, 12M Cache, 1.8GHz (4.4GHz), 15W<br>Intel® Core™ i5-1145G7E Processor, 4C8T, 8M Cache, 1.5GHz (4.1GHz), 15W<br>Intel® Core™ i3-1115G4E Processor, 2C4T, 6M Cache, 2.2GHz (3.9GHz), 15W<br>Intel Industrial Series<br>Intel® Core™ i7-1185GRE Processor, 4C8T, 12M Cache, 1.8GHz (4.4GHz), 15W<br>Intel® Core™ i5-1145GRE Processor, 4C8T, 8M Cache, 1.5GHz (4.1GHz), 15W<br>Intel® Core™ i3-1115GRE Processor, 2C4T, 6M Cache, 2.2GHz (3.9GHz), 15W |
|                  | <b>Memory</b>          | 8GB On-board memory & one SO-DIMM DDR4  |
|                  | <b>BIOS</b>            | AMI SPI 256Mbit   |
| <b>GRAPHICS</b>  | <b>Controller</b>      | Intel® Iris® Xe Graphics for i7/i5 Processors<br>Intel® UHD Graphics for i3/Celeron Processors  |
|                  | <b>Feature</b>         | OpenGL 4.5, DirectX 12, OpenCL 2.1<br>HW Decode: WMV9, AVC/H264, JPEG/MJPEG, HEVC/H265, VP9, AV1<br>HW Encode: AVC/H264, JPEG, HEVC/H265, VP9   |
|                  | <b>Display</b>         | 2 x HDMI, 1 x VGA<br>VGA: resolution up to 1920 x 1200@60Hz<br>HDMI: resolution up to 4096x2160@30Hz  |
|                  | <b>Triple Displays</b> | 1 VGA + 2 HDMI  |
| <b>STORAGE</b>   | <b>Internal</b>        | 1 x M.2 2280 M key (PCIe x4)  |
| <b>EXPANSION</b> | <b>Interface</b>       | 1 x M.2 2280 M key (PCIe x4)<br>1 x M.2 3042/3052 B key (USB3.1)<br>1 x M.2 2230 E Key (PCIe/USB2.0)  |
| <b>ETHERNET</b>  | <b>Controller</b>      | (SKU 1)<br>1 x Intel® I210IT<br>1 x Intel® I225IT<br>(SKU 2)<br>2 x Intel® I210IT<br>1 x Intel® I225IT<br>(SKU 3)<br>2 x Intel® I210IT, 1 x LAN7500i<br>1 x Intel® I225IT   |
| <b>LED</b>       | <b>Indicators</b>      | 1 x Power LED<br>1 x HDD LED  |
| <b>Front I/O</b> | <b>Serial</b>          | 2 x RS-232/422/485 (DB-9, COM 1~2)<br>1 x RS232 (DB9, COM 4)  |
|                  | <b>Display</b>         | 1 x VGA   |
|                  | <b>Buttons</b>         | 1 x Power button<br>1 x Reset button  |

|                                     |                        |   |
|-------------------------------------|------------------------|---|
| <b>Rear I/O</b>                     | Ethernet               | (SKU1) 2 x GbE (RJ-45)<br>(SKU2) 3 x GbE (RJ-45)<br>(SKU3) 4 x GbE (RJ-45)  |
|                                     | Serial                 | 1 x RS-232 or DIO (DB-9, COM 3, Default setting : RS232)  |
|                                     | USB                    | (SKU 1) 6 x USB 3.1 (type A)<br>(SKU 2) 4 x USB 3.1 (type A)<br>(SKU 3) 2 x USB 3.1 (type A)  |
|                                     | Display                | 2 x HDMI  |
| <b>WATCHDOG TIMER</b>               | Output & Interval      | System Reset, Programmable via Software from 1 to 255 Seconds   |
| <b>POWER</b>                        | Type                   | Wide range 9~36V  |
|                                     | Connector              | DC Jack   |
| <b>OS SUPPORT</b>                   | OS Support             | Windows 10 IoT & Linux OS   |
| <b>MECHANISM</b>                    | Construction           | Aluminum + Metal Aluminum   |
|                                     | Mounting               | Wall/VESA/DIN rail mount  |
|                                     | Dimensions (W x H x D) | 181.6mm x 57mm x 118.4mm  |
|                                     | Weight                 | 1.28 kg   |
| <b>ENVIRONMENT</b>                  | Operating Temperature  | -20 to 60°C (wide-temp SSD)   |
|                                     | Storage Temperature    | -20 to 85°C   |
|                                     | Relative Humidity      | 5 to 95% RH (non-condensing)  |
| <b>STANDARDS AND CERTIFICATIONS</b> | Shock                  | Operating:<br>IEC 60068-2-27 Test Ea: Shock Test<br>Half-Sine, 3G @ 11ms, 18 Shock $\pm X$ , $\pm Y$ , $\pm Z$ (each axis 3 times)  |
|                                     | Vibration              | Operating:<br>IEC 60068-2-64 Test Fh: Vibration Board-Band Random Test Random, 1Grms @ 5~500 Hz, 30min<br>Non-Operating:<br>IEC 60068-2-6 Test Fc: Vibration Sinusoidal Test<br>Sweep Sine, 3Grms @ 10~500Hz, 30min |
|                                     | Certifications         | CE, FCC Class A, RoHS   |

## Chapter 2 - Hardware Installations

### ► Removing the Chassis Cover

Please read and follow the instructions below to open the system.

1. Make sure the system and all other peripheral devices connected to it have been powered off.
2. Disconnect all power cords and cables.

#### Step 1:

The 2 screws on the bottom of the system are used to secure the bottom cover to the chassis. Remove the screws and put them in a safe place for later use. Lift the bottom cover upward to open the system.



#### Step 2:

The heat shield can be easily accessed after the chassis cover is removed.




### ► Installing the SO-DIMM Module

Before installing the memory module, please read and follow the safety cautions below.

1. Make sure the PC and all other peripheral devices connected to it has been powered down.
2. Disconnect all power cords and cables.
3. Locate the SO-DIMM socket on the system board.
4. Make sure the notch on memory card is aligned to the key on the socket.


#### Step 1:

Remove the 4 screws of the heat shield and put them in a safe place for later use. Remove the heat shield and the SO-DIMM socket is readily accessible.




#### Step 2:

Insert the memory card into the slot while making sure 1) the notch and the key are aligned, and 2) the non-connector end rises approximately 45 degrees horizontally. Press the card firmly into the socket while applying and maintaining even pressure on both ends.




#### Step 3:

Press the end of the card far from the socket down while making sure the retention notch and the clip align as indicated by the dotted line in the illustration. If the retention notch and the clip do not align, please remove the card and re-insert it. Press the card all the way down.




#### Step 4:

The clips snap automatically and abruptly to the retention notches of the card sounding a distinctive click, and lock the card in place. Inspect that the clip sits in the notch. If not, please pull the clips outward, release and remove the card, and mount it again.



► COM3 Jumper Setting

Remove the 4 screws of the heat shield and put them in a safe place for later use.  
Remove the heat shield and the COM 3 jumper is readily accessible.




A JP9

| Pin   | Assignment      | Pin   | Assignment |
|-------|-----------------|-------|------------|
| 1-2   | RS232 (default) | 2-3   | DIO        |
| 4-5   |                 | 5-6   |            |
| 7-8   |                 | 8-9   |            |
| 10-11 |                 | 11-12 |            |

B JP8

| Pin   | Assignment      | Pin   | Assignment |
|-------|-----------------|-------|------------|
| 1-2   | RS232 (default) | 2-3   | DIO        |
| 4-5   |                 | 5-6   |            |
| 7-8   |                 | 8-9   |            |
| 10-11 |                 | 11-12 |            |

► COM Port Jumper Setting



| Pin  | RS232 | RS422 (Full Duplex) | RS485 | DIO   |
|------|-------|---------------------|-------|-------|
| Pin1 | DCD   | RX+                 | DATA+ | DIOA0 |
| Pin2 | RXD   | RX-                 | DATA- | DIOA1 |
| Pin3 | TXD   | TX+                 | NC    | DIOA2 |
| Pin4 | DTR   | TX-                 | NC    | DIOA3 |
| Pin5 | GND   | GND                 | GND   | GND   |
| Pin6 | DSR   | NC                  | NC    | DIOA4 |
| Pin7 | RTS   | NC                  | NC    | DIOA5 |
| Pin8 | CTS   | NC                  | NC    | DIOA6 |
| Pin9 | RI    | NC                  | NC    | DIOA7 |

## Chapter 3 - BIOS Settings

### ► Overview

The BIOS is a program that takes care of the basic level of communication between the CPU and peripherals. It contains codes for various advanced features found in this system board. The BIOS allows you to configure the system and save the configuration in a battery-backed CMOS so that the data retains even when the power is off. In general, the information stored in the CMOS RAM of the EEPROM will stay unchanged unless a configuration change has been made such as a hard drive replaced or a device added. It is possible that the CMOS battery will fail causing CMOS data loss. If this happens, you need to install a new CMOS battery and reconfigure the BIOS settings.



#### Note:

The BIOS is constantly updated to improve the performance of the system board; therefore the BIOS screens in this chapter may not appear the same as the actual one. These screens are for reference purpose only.

#### Default Configuration

Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.

#### Entering the BIOS Setup Utility

The BIOS Setup Utility can only be operated from the keyboard and all commands are keyboard commands. The commands are available at the right side of each setup screen. The BIOS Setup Utility does not require an operating system to run. After you power up the system, the BIOS message appears on the screen and the memory count begins. After the memory test, the message "Press DEL to run setup" will appear on the screen. If the message disappears before you respond, restart the system or press the "Reset" button. You may also restart the system by pressing the <Ctrl> <Alt> and <Del> keys simultaneously.

### Legends

| Keys               | Function   |
|--------------------|--|
| Right / Left arrow | Move the highlight left or right to select a menu                      |
| Up / Down arrow    | Move the highlight up or down between submenus or fields               |
| <Enter>            | Enter the highlighted submenu  |
| + (plus key)/F6    | Scroll forward through the values or options of the highlighted field  |
| - (minus key)/F5   | Scroll backward through the values or options of the highlighted field |
| <F1>               | Display general help   |
| <F2>               | Display previous values  |
| <F7>               | Popup Boot Device List   |
| <F9>               | Optimized defaults   |
| <F10>              | Save and Exit  |
| <Esc>              | Return to previous menu  |

#### Scroll Bar

When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.

#### Submenu


When "►" appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press <Enter>.

### ► Updating the BIOS

To update the BIOS, you will need the new BIOS file and a flash utility. Please contact technical support or your sales representative for the files and specific instructions about how to update BIOS with the flash utility.

► Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



**System Date**

The date format is <month>, <date>, <year>. Press "Tab" to switch to the next field and press "-" or "+" to modify the value.

**System Time**


The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.

► Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.




**Important:**  
Setting incorrect field values may cause the system to malfunction.



▶ Advanced

CPU Configuration



**Intel (VMX) Virtualization Technology**

When this field is set to Enabled, the VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

**Active Processor Cores**

Select number of cores to enable in each processor package: all or 1.

**Hyper-threading**

Enables this field for Windows XP and Linux which are optimized for Hyper-Threading technology. Select disabled for other OSes not optimized for Hyper-Threading technology. When disabled, only one thread per enabled core is enabled.


▶ Advanced

Power & Performance



▶ Advanced

Power & Performance ▶ CPU- Power Management Control



**Intel (R) SpeedStep(tm)**

This field is used to enable or disable the Intel SpeedStep® Technology, which helps optimize the balance between system's power consumption and performance. After it is enabled in the BIOS, EIST features can then be enabled via the operating system's power management.

**Turbo Mode**


Enable or disable turbo mode of the processor. This field will only be displayed when EIST is enabled.

**C states**

Enable or disable CPU Power Management. It allows CPU to enter "C states" when it's idle and nothing is executing.

▶ Advanced

PCH-FW Configuration



**ME State**

When this field is set to Disabled, ME will be put into ME Temporarily Disabled Mode.

**Manageability Features State**

Enable or disable Intel(R) Manageability features. This option disables/enables Manageability Features support in FW. To disable, support platform must be in an unprovisioned state first.

**AMT BIOS Features**

When disabled, AMT BIOS features are no longer supported and user is no longer able to access MEBx Setup. This option does not disable manageability features in FW.

**ME Unconfig on RTC Clear**

When disabled, ME will not be unconfigured on RTC Clear.



**Note:**  
The sub-menus are detailed in following sections.

▶ Advanced

### Trusted Computing



#### Security Device Support


This field is used to enable or disable BIOS support for the security device such as an TPM 2.0 to achieve hardware-level security via cryptographic keys.

#### Pending operation

To clear the existing TPM encryption, select "TPM Clear" and restart the system. This field is not available when "Security Device Support" is disabled.

▶ Advanced

### NCT6126D Super IO Configuration



#### WatchDog Timer Unit

Select WatchDog Timer Unit – Second or Minute.

#### SuperIO WatchDog Timer


Set SuperIO WatchDog Timer Timeout value. The range is from 0 (disabled) to 255.



**Note:**  
The sub-menus are detailed in following sections.

► Advanced

NCT6126D HW Monitor




This section displays the system's health information, i.e. voltage readings, CPU and system temperatures, and fan speed readings

**Case Open**

Enable or disable the case open detection function.

► Advanced

NCT6126D HW Monitor ► Smart FAN Function



Smart Fan is a fan speed moderation strategy dependent on the current system temperature. When the system temperature goes higher than the Boundary setting, the fan speed will be turned up to the setting of the Fan Speed Count that bears the same index as the Boundary field.

**SYS Smart Fan/CPU Smart Fan Control = [Enabled]**

• **Boundary 1 to Boundary 4**

Set the boundary temperatures that determine the fan speeds accordingly, the value ranging from 0-127°C. For example, when the system temperature reaches Boundary 1 setting, the fan speed will be turned up to the designated speed of the Fan Speed Count 1 field.

• **Fan Speed Count 1 to Fan Speed Count 4**

Set the fan speed, the value ranging from 1-100%, 100% being full speed. The fans will operate according to the specified boundary temperatures above-mentioned.


**SYS Smart Fan/CPU Smart Fan Control = [Disabled]**

• **Fix Fan Speed Count**

Set the fan speed, the value ranging from 1-100%, 100% being full speed. The fans will always operate at the specified speed regardless of gauged temperatures.

► Advanced

Serial Port Console Redirection




**Console Redirection**

By enabling Console Redirection of a COM port, the sub-menu of console redirection settings will become available for configuration as detailed in the following.

► Advanced

Serial Port Console Redirection ► Console Redirection Settings



Configure the serial settings of the current COM port.

**Terminal Type**

Select terminal type: VT100, VT100+, VT-UTF8 or ANSI.

**Bits per second**

Select serial port transmission speed: 9600, 19200, 38400, 57600 or 115200.

**Data Bits**

Select data bits: 7 bits or 8 bits.

**Parity**

Select parity bits: None, Even, Odd, Mark or Space.

**Stop Bits**

Select stop bits: 1 bit or 2 bits.

**Flow Control**

Select flow control type: None or Hardware RTS/CTS. Flow Control is for RS485 mode and is only supported by Serial Port 1 (COM1).

► Advanced

**VT-UTF8 Combo Key Support**

Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals.

**Recorder Mode**

With this mode enabled only text will be sent. This is to capture Terminal data.

**Resolution 100x31**


Enables or disables extended terminal resolution

**Putty KeyPad**

Select FunctionKey and KeyPad on Putty.

► Advanced

ACPI Settings



**Wake system from S5 via RTC**

When Enabled, the system will automatically power up at a designated time every day. Once it's switched to [Enabled], please set up the time of day – hour, minute, and second – for the system to wake up.


**State After G3**

Select between S0 State, and S5 State. This field is used to specify what state the system is set to return to when power is re-applied after a power failure (G3 state).

- **S0 State** The system automatically powers on after power failure.
- **S5 State** The system enter soft-off state after power failure. Power-on signal input is required to power up the system.
- **Last State** The system returns to the last state right before power failure.

► Advanced

## USB Configuration



### Legacy USB Support

- **Enabled** Enable Legacy USB support.
- **Disabled** Keep USB devices available only for EFI applications.
- **Auto** Disable Legacy support if no USB devices are connected.

### XHCI Hand-off


Enable or disable XHCI Hand-off.

### USB Mass Storage Driver Support

Enable or disable USB Mass Storage Driver Support.

► Advanced

## Network Stack Configuration



### Network Stack

Enable or disable UEFI network stack. The following fields will appear when this field is enabled.

### IPv4 PXE Support

Enable or disable IPv4 PXE boot support. If disabled, IPv4 PXE boot support will not be available.

### IPv4 HTTP Support

Enable or disable IPv4 HTTP boot support. If disabled, IPv4 HTTP boot support will not be available.

### IPv6 PXE Support

Enable or disable IPv6 PXE boot support. If disabled, IPv6 PXE boot support will not be available.

### IPv6 HTTP Support

Enable or disable IPv6 HTTP boot support. If disabled, IPv6 HTTP boot support will not be available.

### PXE boot wait time


Set the wait time in seconds to press ESC key to abort the PXE boot. Use either +/- or numeric keys to set the value.

### Media detect count

Set the number of times the presence of media will be checked. Use either +/- or numeric keys to set the value.

▶ **Advanced**

**CSM Configuration**



**CSM Support**

This section is used to enable or disable CSM Support. The following fields are only available when "CSM Support" is enabled.

**Boot option filter**

This field controls Legacy/UEFI ROMs priority. Select among UEFI and Legacy, Legacy only or UEFI only.

**Network**

This field controls the execution of UEFI and Legacy Network OpROM.

**Storage**

This field controls the execution of UEFI and Legacy Storage OpROM.

**Video**


This field controls the execution of UEFI and Legacy Video OpROM.

**Other PCI devices**

This field determines OpROM execution policy for devices other than Network, Storage or Video.

▶ **Advanced**

**Tls Auth Configuration**



**Server CA Configuration**

Press <Enter> to configure Server CA.


► Chipset



Please select a submenu and press Enter. The submenus are detailed in the following pages.

► Chipset

Graphics Configuration



**Primary Display**

Select which of IGFX/PEG/PCI Graphics device to be the primary display.

**Internal Graphics**

Keep IGFX "Enabled" or "Disabled" based on the setup options, or select "Auto" for auto-detection.

**GTT Size**

Select the GTT Size

**Aperture Size**

Select the Aperture Size. Note: Above 4GB MMIO BIOS assignment is automatically enabled when selecting 2048MB aperture. To use this feature, please disable CSM Support.

**DVMT Pre-Allocated**

Select DVMT 5.0 Pre-Allocated (Fixed) Graphics Memory Size used by the Internal Graphics Device.

**DVMT Total Gfx Mem**

Select DVMT 5.0 Total Graphic Memory Size used by the Internal Graphics Device.

▶ Chipset

PCH-IO Configuration



**PCI Express Configuration**

PCI Express Configuration Settings

**SATA And RST Configuration**

SATA Device Options Settings

**HD Audio Configuration**

HD Audio Subsystem Configuration Settings

▶ Chipset

PCH-IO Configuration ▶ PCI Express Configuration



Select one of the PCI Express channels and press enter to configure the following settings.

**LAN 1, LAN2, M.2-E, M.2-B**


Control the PCI Express Root Port.

**PCIe Speed**

Select PCIe Speed of the current port – AUTO, Gen1, Gen 2, or Gen3. This field may not appear when the speed of the port is not configurable.

► Chipset

PCH-IO Configuration ► SATA And RST Configuration



**SATA Controller(s)**

This field is used to enable or disable the Serial ATA controller.

**SATA Speed**

This field is used to select SATA speed generation limit: Auto, Gen1, Gen2 or Gen3.

**SATA Mode Selection**

The mode selection determines how the SATA controller(s) operates.

- **AHCI** This option allows the Serial ATA controller(s) to use AHCI (Advanced Host Controller Interface).
- **Intel RST Premium With Intel Optane System Acceleration** This option allows you to create RAID or Intel Rapid Storage configuration along with Intel® Optane™ system acceleration on Serial ATA devices.

**Ports and Hot Plug**

Enable or disable the Serial ATA port and its hot plug function.

► Chipset

PCH-IO Configuration ► HD Audio Configuration




**HD Audio**

Control the detection of the HD Audio device.

- **Disabled** HDA will be unconditionally disabled.
- **Enabled** HDA will be unconditionally enabled.

► Security



**Administrator Password**


Set the administrator password. To clear the password, input nothing and press enter when a new password is asked. Administrator Password will be required when entering the BIOS.

**User Password**

Set the user password. To clear the password, input nothing and press enter when a new password is asked. User Password will be required when powering up the system.

► Security

Secure Boot



**Secure Boot**

The Secure Boot store a database of certificates in the firmware and only allows the OSEs with authorized signatures to boot on the system. To activate Secure Boot, please make sure that "Secure Boot" is "[Enabled]", Platform Key (PK) is enrolled, "System Mode" is "User", and CSM is disabled. After enabling/disabling Secure Boot, please save the configuration and restart the system. When configured and activated correctly, the Secure Boot status will be "Active".

**Secure Boot Customization**

Select the secure boot mode – Standard or Custom. When set to Custom, the following fields will be configurable for the user to manually modify the key database.


**Restore Factory Keys**

Force system to User Mode. Load OEM-defined factory defaults of keys and databases onto the Secure Boot. Press Enter and a prompt will show up for you to confirm.

**Reset To Setup Mode**

Clear the database from the NVRAM, including all the keys and signatures installed in the Key Management menu. Press Enter and a prompt will show up for you to confirm.

## ► Boot

**Setup Prompt Timeout**

Set the number of seconds to wait for the setup activation key. 65535 (0xFFFF) denotes indefinite waiting.

**Bootup NumLock State**

Select the keyboard NumLock state: On or Off.

**Quiet Boot**

This section is used to enable or disable quiet boot option.

**Boot Option Priorities**

Rearrange the system boot order of available boot devices.


**Fast Boot**

Enables or disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.

**Note:**

If "Boot option filter" of "CSM Configuration" is set to "UEFI and Legacy" or "UEFI only", and "Quiet Boot" is set to enabled, "BGRT Logo" will show up for configuration. Refer to the Advanced > CSM Configuration submenu for more information.

## ► Save &amp; Exit

**Save Changes and Reset**

To save the changes, select this field and then press <Enter>. A dialog box will appear. Select Yes to reset the system after saving all changes made.

**Discard Changes and Reset**

To discard the changes, select this field and then press <Enter>. A dialog box will appear. Select Yes to reset the system setup without saving any changes.

**Restore Defaults**

To restore and load the optimized default values, select this field and then press <Enter>. A dialog box will appear. Select Yes to restore the default values of all the setup options.

**Boot Override**

Move the cursor to an available boot device and press Enter, and then the system will immediately boot from the selected boot device. The Boot Override function will only be effective for the current boot. The "Boot Option Priorities" configured in the Boot menu will not be changed.

- **Save Setting to file** Select this option to save BIOS configuration settings to a USB flash device.
- **Restore Setting from file** This field will appear only when a USB flash device is detected. Select this field to restore setting from the USB flash device.